# 32" HD Google TV

# CHIQ

**L32M9P** 

Google Assistant External Powerbank Portable TV

DISPLAY SIZE

32" / 81cm

RESOLUTION

HD

**AUDIO** 

DOLBY DAP DBX-TV Dolby/Dolby+









\*Powerbank needs to be purchased separately.

#### **FEATURES**



Google TV smart TVs and streaming devices bring together everything you stream on one screen. So you can find what to watch without jumping from app to app.



Personal Google Assistant is always ready to help.



A global online store to find, enjoy, and share your favourite apps, games, movies, music, and books on all your favourite devices.



Watch thousands of TV shows, movies, and Netflix original programming on your TV.



See what the world is watching, the hottest music videos, news and more.



Enjoy thousands of online streaming videos with Amazon Prime Video.

#### Multiscreen

Cast your favourite entertainment content from your Android or iOS device with Google Cast / DLAN / Airplay.



High-dynamic-range video. Key feature of HDR video are brighter whites, deeper blacks.



Superior sound enhancement from the TV-audio experts.



Dolby Audio uses advanced processing technology to create a dynamic audio experience.

# DC 12V Powerbank (Optional Accessory)

Power banks are lightweight and compact, allowing you to move your TV setup anywhere. Stay connected during long drives, camping trips and even power outages.



HLG is designed for broadcast cable, satellite and live TV. It uses multiple routes to progress picture quality and produce vivid images.

## Dual-band Wi-Fi

2.4GHz/5GHz dual-band Wi-Fi is available, your CHiQ TV can connect to either the 2.4 or 5 GHz networks

#### Personalized Entertainment

With personal profiles, discover new favorites with recommendations just for you. Save shows and movies to your personal watchlist. Create a space for kids that's all their own, with watch limits, bedtimes and more.

#### ROM (8GB)

The 8GB of ROM stores more content and which supports a very fluent operation.

#### Quad Core CPU

The powerful quad core A55 enables smoother and more stable images to improve the users viewing experience.

## Bluetooth 5.0

Bluetooth 5.0 can transmit eight times more data, at twice the speed, across four times the range than Bluetooth 4.2.



Thinner borders, larger display. Picture or video occupies the whole TV screen. The picture seems bigger than regular televisions.

# Google TV



DISPLAY		PRODUCT	
Resolution	1366 x 768	Net Size without Stand (W*D*H)	718x84.1x421.6 mm
Size	31.5"	Net Size with Stand (W*D*H)	718*199.6*448.5 mm
Screen Type	DLED	Package Size (W*D*H)	793*117*487 mm
Brightness	UP to 200nit	Weight	Net 3.7 / Gross 4.8 KG
Contrast Ratio	3000:1	VESA	200 x 200 mm
Refresh Rate	60Hz	USB Recording	Yes (DTV only)
View Angle	178°(H) /178°(V)		
Response Time	6.5 ms		

PLATFORM		PRE-LOAD APPS
CPU GPU Memory Operation System	CA55*4@1.1Ghz G31 MP2@550Mhz 1.5GB RAM / 8GB ROM Google TV	Netflix, Amazon Prime Video, LiveTV, YouTube, Google Play  Movies & TV, Google Play Store, Media, Google Play Game, etc.


TERMINALS		AUDIO	
LAN	1	Audio Power Output	2 x 8 WATT
RF IN	1	Sound Mode	Standard / Vivid / Sports / Movie / Music / News
AV IN HDMI	1 2 (V1.4)	Sound Control	Balance/AVL
EARPHONE	1	Sound Effect	Dolby DAP / Dolby/Dolby+ / DBX
Optical	1	Subwoofer Surround	NO YES
		Stereo	YES
		Auto volume control	YES

POWER		IMAGE	
Power Consumption (Standby)	≤0.5W	Picture Modes	User / Standard / Vivid / Sport / Movie / Game / Energy Saving
Power Source	AC 100V -240V 50 / 60 Hz	HDR System	HDR10 / HLG
Energy Rate	TBD	HEVC (H.265) Decoder	Yes

#### Powering the TV




- Insert the power cable into the POWER connector on the back of the TV.
- Make sure the power cable is securely inserted in the connector.
- When you unplug the power cable, always pull the plug, never pull the cable.



## 5000mAh Powerbank (Optional Accessory)

- Attach the bracket to the TV and secure the bracket with hand screws.
- Place the power bank in the holder to complete the installation.
- Connect the TV and power bank with a type-c cable to power the TV.



#### **Details of components**


Purchase in the form of spare parts through CHiQ after-sales department.




**Bracket** 



Screws



Powerbank



type-c cable

#### **Precautions**

- Playing TV while charging results in poor charging effect. It is not recommended to connect an adapter to a power bank to supply power to the TV.
- The idle time of power banks should not be too long, which may cause the battery to run out. The maximum idle time is 6 months.
- If you do not plan to use the device for an extanded period, please remove the
- battery and keep it in room temperature (around 20°C)